

Link: <https://help.wextelematics.com/installation-video/gpsi-3900e-jpod/> Last Updated: January 8th, 2016

This video walks you through the following steps in the installation on process:

1. Locate the vehicle's diagnostic port, and ensure proper voltage.
2. Install the external antenna, and route the cables.
3. Free up existing JPort, and install bypass cable.
4. Mount the replacement diagnostic port.
 - INSTALL OPTIONAL ACCESSORIES -
5. Prep the harness, and connect the jPOD to the harness AUX 2.
6. Connect the antenna cables to the device.
7. Connect the harness, and mount the device.
8. Connect the jPOD to the bypass cable.
9. Verify installation, and tamper-proof remaining connections.