GPSI-3900E jPOD



Link: https://help.wextelematics.com/installation-video/gpsi-3900e-jpod/ Last Updated: January 8th, 2016

This video walks you through the following steps in the installation on process:

- 1. Locate the vehicle's diagnostic port, and ensure proper voltage.
- 2. Install the external antenna, and route the cables.
- 3. Free up existing JPort, and install bypass cable.
- 4. Mount the replacement diagnostic port.
 - INSTALL OPTIONAL ACCESSORIES -
- 5. Prep the harness, and connect the jPOD to the harness AUX 2.
- 6. Connect the antenna cables to the device.
- 7. Connect the harness, and mount the device.
- 8. Connect the jPOD to the bypass cable.
- 9. Verify installation, and tamper-proof remaining connections.