


You can update maintenance reminders or delete maintenance reminders.

Update a Maintenance Reminder

When service has been performed on a vehicle, update the reminder for the next service.

► To update a reminder:

1. From the Search Results tab or Maintenance tab, click the reminder that you want to edit.
2. From the Maintenance Card, click **Update**.
3. Update the Next Service value:
 - If an Interval value is set, click **Reset** to automatically calculate the Next Service mileage and/or hours value(s) by adding the chosen interval value to the vehicle's current odometer and/or run time.



The screenshot shows a maintenance card for an 'Oil Change' service. The card displays the following information: Vehicle: 51 LINDA, Odometer: 40,889 miles (circled in red), Runtime: 34 hours, Interval: n/a, and Next: 03/10/2015. Below the card, there are 'Update' and 'Delete' buttons. To the right of the card, the 'Next Service' section is visible, which includes a text input field for miles (41000) and a text input field for hours (43889). A red dashed arrow points from the miles input field to the hours input field. Below these fields, there is a 'Reset' button (with a hand cursor icon) and an 'Intervals' section with a text input field for miles (3000, circled in red) and a text input field for hours.

- If an Interval value is not set, enter a free-form value for miles, hours, or date for the next service.

1. Click **Save**.

Delete a Maintenance Reminder

When you delete a maintenance reminder, any service reminder alerts that are based on that vehicle will still remain active.

► To delete a reminder:

1. From the Search Results tab or Maintenance tab, click the reminder that you want to delete.
2. From the Maintenance Card, click **Delete**.
3. In the Delete Maintenance pop-up window, click **OK**.